



Whole chain demonstration

Vienna, 27.04.2022



This project has received funding
from European Union's Horizon 2020
research and innovation programme
under grant agreement n° 764675





BEST

Bioenergy and
Sustainable Technologies

Scope

- Demonstrating the APR process on lab-scale
- Benchmarking the full-scale millistructured FT reactor
- Produce FT diesel compliant with fuel standards
- Connecting the wet and dry route





APR process demonstration

Scale-up

Aqueous phase


Carboxylic acids
Alcohols
Ketones
Polyalcohols
Aromatics
Aldehydes

APR


Product gas

Hydrogen
Carbon dioxide

Scale-up factor



APR process demonstration unit



APR reactor



Designed by **PoliTo/Khimod**
Manufactured by **Khimod**

Key facts

- Commissioned in Q2 2021
- Able to continuously process up to 44 l/h of AP
- Max. allowable conditions: 70 barg and 290 °C
- Equipment made from 306/306L stainless steel
- Fully automated using an industrial PLC
- Certified by TÜV Austria

Summary

Key achievements

- Continuous APR demonstrated in lab-scale for 250+ h
- Of that 100 h in one continuous test run (Mon 08:00 to Fri 12:00)
- Demonstrated operatorless operation overnight from 18:00 to 07:00
- Maximum of 500+ NI/h gas produced


Conclusions

- Higher temperatures increase conversion
- Higher pressures decrease conversion
- Gas quality not significantly impacted by pressure and temperature
- Catalyst showed no signs of deactivation over 229 days (250+ h net operating time)




Full-scale millistructured FT reactor


Fischer-Tropsch synthesis



Lab-scale FT unit



FT reactor



Designed by **CEA**
Manufactured by **Khimod**

Key facts

- Originally designed for a SBCR (3.5 to 7.5 Nm³/h syngas)
- Rebuilt to accomidate the full-scale millistructured reactor
- Integrated APR gas supply
- Commissioned in Q4 2021
- Fully automated using an industrial PLC

FT product

Light liquid hydro carbons

- Condensed at $\sim 5^{\circ}\text{C}$ and 20 barg
- Liquid at ambient temperature
- ~ 25 wt.% of total condensables





Heavy liquid hydro carbons

- Condensed at $\sim 60^{\circ}\text{C}$ and 20 barg
- Liquid at ambient temperature
- ~ 15 wt.% of total condensables



Wax

- Condensed at $\sim 150^{\circ}\text{C}$ and 20 barg
- Solid at ambient temperature
- ~ 60 wt.% of total condensables



Fuel analysis

Diesel was obtained through vacuum distillation from wax



Fuel analysis performed by CRF

Tested for compliance with EN 15940 Automotive fuels -
Paraffinic diesel fuel from synthesis or hydrotreatment

Sample met all limits defined in EN 15940 Class A



Summary

Key achievements


- 300+ h of operating time
- 6.4 kg of condensable FT product produced
- Diesel from FT experiments complied with the standard

Conclusions

- Similar CO conversion to intermediat scale
- Very long-chain product

Coupled APR/FT operation

Connecting wet and dry route



Summary

Key achievements

- 50 h of non-stop coupled operation
- 15 vol.% of syngas substituted by APR product gas
- Comparable CO conversion achieved for coupled operation

THANK YOU

This document and all information contained here in is the sole property of the Heat-to-Fuel Consortium or the company referred to in the slides. It may contain information subject to Intellectual Property Rights. No Intellectual Property Rights are granted by the delivery of this document or the disclosure of its content.

Reproduction or circulation of this document to any third party is prohibited without the written consent of the author(s).

The statements made here in do not necessarily have the consent or agreement of the Heat-to-Fuel Consortium and represent the opinion and findings of the author(s).

The dissemination and confidentiality rules as defined in the Consortium agreement apply to this document.

All rights reserved.